



THE AMERICAN  
UNIVERSITY IN CAIRO

Spring 2023

# **CSCE 363/3611 - Digital Signal Processing**

## **Project: ECG Processing**


Seif Eldawlatly

# ECG and Heart Signals

- References:
  - U.R. Acharya, J.S. Suri, J.A.E. Spaan, S.M. Krishnan, "Advances in Cardiac Signal Processing", Springer (Chapter 1) (available through Springer)
  - K. Blinowska and J. Zygiereicz, "Practical Biomedical Signal Analysis Using Matlab," CRC Press, Boca Raton, FL, USA, 2011 (Chapter 4: Section 4.2) (available through AUC Library website)

# ECG Waveform


- A typical Electrocardiogram (ECG) signal of a normal person is as follows:



- P-wave corresponds to the depolarization of the atria and indicates the start of atrial contraction that pumps blood to the ventricles
- The Q, R, and S waves are usually treated as a single composite wave known as the QRS-complex. The QRS-complex reflects the depolarization of ventricles, and indicates the start of ventricular contraction that pumps blood to the lungs and the rest of the body

# ECG Waveform

- A typical Electrocardiogram (ECG) signal of a normal person is as follows:




- The T-wave corresponds to the repolarization of the ventricles, which is a necessary recovery process for the heart to depolarize and contract again. The end of the T-wave coincides with the end of ventricular contraction. Atrial repolarization (Ta-wave) is usually not visible as it normally coincides with the QRS-complex (and is buried in the larger waveform)

# ECG Signal Processing


- The first step in ECG signal processing is artifact removal
- ECG maybe corrupted with two types of artifacts:
  - Technical artifacts: such as power line interferences, artifacts due to bad electrode contacts, quantization or aliasing errors, noise generated by other medical equipment present in the patient care environment
  - Biological artifacts: such as patient-electrode motion artifacts, muscular activity, baseline drift—usually due to respiration
- Technical artifacts may be avoided by designing proper measurement procedures. Elimination of biological artifacts is much more difficult and requires special signal analysis techniques

# ECG Signal Processing: Noise Filtering


- A typical noisy ECG signal will appear along with a 50Hz (or 60 Hz) mains noise



- A notch filter with a filtered frequency of 50Hz can be used to remove the baseline 50Hz




- Example of a notch Filter with a stop frequency of 2000 Hz



# ECG Signal Processing: Noise Filtering


- The ECG signal is further filtered using a Band-pass filter with a bandwidth of 0.1-45 Hz



- Cut-off frequency above 0.8Hz would distort the ECG waveform

# ECG Signal Processing: Morphological Features


- Clinical assessment of ECG mostly relies on evaluation of its time domain morphological features such as positions, durations, amplitudes, and slopes of its complexes and segments





# ECG Signal Processing: Morphological Features


- The first step in the analysis is usually detection of the QRS complex; it serves as a marker for averaging of heart cycles, for evaluation of heart rate, for finding the heart axis
- One way to detect ECG is to use a single threshold above which any signal would be considered as part of the QRS complex
- One problem with this method is baseline drift with which a single threshold might detect false signals



**Baseline Drift**

# ECG Signal Processing: Morphological Features

- One way to overcome baseline drifts is to **differentiate** the ECG signal since we are looking for large slopes in the signal



- To do the derivative, the following 5-point difference equation can be used


$$y(nT) = (1/8T) [-x(nT - 2T) - 2x(nT - T) + 2x(nT + T) + x(nT + 2T)]$$

# ECG Signal Processing: Morphological Features


- The next step is to **square the derivative**. This makes all data points positive and does nonlinear amplification of the output of the derivative emphasizing the higher frequencies (i.e., predominantly the ECG frequencies)

$$y(nT) = [x(nT)]^2$$

After Differentiation



After Squaring




# ECG Signal Processing: Morphological Features

- The next step is to **smooth the squared signal** using a moving average window

$$y(nT) = (1/N) [x(nT - (N - 1) T) + x(nT - (N - 2) T) + \dots + x(nT)]$$

where  $N$  is the number of samples in the width of the moving average window



- $N$  should be set approximately the same as the widest possible QRS complex



# ECG Signal Processing: Morphological Features

- The final step is to **set a threshold** on the moving average output. The peak value above the threshold within the moving average window is approximately the R wave

R Wave



# Heart Rate Variability Analysis


- The sequence of RR intervals—that is, all intervals between adjacent QRS complexes resulting from sinus node depolarizations—forms the RR interval time series or RR tachogram

$$RR_i = t_i - t_{i-1}$$

- A corresponding sequence of instantaneous heart rate is defined as


$$ff_i = \frac{1}{RR_i}$$

- Heart rate variability (HRV) is a physiological phenomenon of the variation of the time interval between heartbeats



# Heart Rate Variability Analysis

- Symptoms and diseases affect the HRV signal. For example, the HRV of a heart with a period of artery occlusion will be as shown below



# Heart Disorders and ECG

- Looking at an ECG, one can determine the type of heart disorder of a patient
- The manner in which the heart contracts over time determines the rhythm of the heart
- **Normal sinus rhythm** (NSR) is the normal rhythm of the heart when there is no disease or disorder affecting it. NSR is characterized by a heart rate of 60 to 100 beats per minute
- The regularity of the R-R interval varies slightly with the breathing cycle, typically shortening slightly during respiration



# Sinus Node Arrhythmias

- The arrhythmia arises from the S-A node for this group of disorders. Since the electrical impulse is generated from the normal pacemaker, the consistent characteristic feature of these arrhythmias is that P-wave wave shape of the ECG is normal
- Sinus Arrest:  
The S-A node intermittently fails to fire. There is no P-wave and therefore no accompanying QRS-complex and no T-wave

